



FINANCIAL SERVICES

Vehicle Service Contract

MARINE



EXTENDED PROTECTION THAT GOES THE DISTANCE

The Bass Pro Shops Financial Services Vehicle Service Contract (VSC) is the added protection you need beyond your Marine warranty. We provide seamless coverage so you can explore the great outdoors with confidence.

VEHICLE ELIGIBILITY

NEW VSC PLANS

Your boat is eligible if it's covered under your manufacturer's warranty and is one (1) model year old or less.

PRE-OWNED VSC PLANS

Your boat is eligible if it's five (5) model years old or less. Only available at the time of purchase.

Ask your Sales Consultant about the advantages of Vehicle Service Contracts and other Bass Pro Shops Financial Services Protection Products.

COVERAGE BENEFITS



Lift out and hoist out reimbursement



Dock assistance



Travel protection



Deductible options²



Repairs using genuine parts, performed by factory-trained technicians keeping your boat at peak performance



100% transferable, one time at no additional cost

Covered Components List

VSC COVERS INBOARD AND OUTBOARD ENGINES AND ALL INTERNALLY LUBRICATED PARTS.³

ENGINE

All internally lubricated parts including pistons, rings, and pins; crankshaft, main bearings, connecting rods, and connecting rod bearings; oil pump, reed, and reed blocks; cylinder heads; flywheel. **CYLINDER BLOCK IF DAMAGED BY THE RECIRCULATING PUMP I/O INTERNALLY LUBRICATED PART ONLY.**

LOWER UNIT

Gearcase head, bearings, and oil retainers; driveshaft(s) upper bearings; shift rod, and shift rod cover assembly; pinion bearing, forward gear, and forward pinion; reverse gear, shift lever, and dog; **GEARCASE AND/OR PROPELLER SHAFT IF DAMAGED BY A COVERED INTERNALLY LUBRICATED PART** (excluding water pump). **TRANSMISSION:** seals, gaskets, gears, clutch, bushings, mounts, and all internally lubricated parts. **MIDSECTION:** yoke coupler end, yoke-gear end, cross, and bearing, u-joints, coupler, bearings, gimbal bearings, gimbal housing, transom plate, gimbal ring assembly, roller bearing assembly, shims, retainers, O-rings, steering pivot bushing, steering arm bushing, steering, and tilt bearing. **UPPER HOUSING:** all internally lubricated parts, including gears, shims, driveshaft upper bearings, roller bearing, seals, shims, drive gear, pinion gear, inner, and outer pinion carrier bearings, bearing carrier, and drive gear bearing. **LOWER HOUSING:** all internally lubricated parts, including bearings, gears, shift shaft, shims, clutch, driveshaft, roller bearing, pinion gear, prop shaft, lower and upper driveshaft bearings, and retainers.

FUEL & OIL PUMP

Fuel tank; fuel tank sending unit; fuel pump; oil injection system; oil injection metering system; injection pump; oil injection drive gear/shaft; oil injection check valve; pulse limiter and hose; oil tank; oil cap, oil level and oil flow warning sensors, and control modules; oil level warning horn; oil lines (excluding rubber lines and hoses); fuel injection; DFI and EFI components; fuel injectors; oil pump; EAP sensor; MAP sensor; TPS sensor inner and outer; crank position sensor; water temperature sensor; air temperature sensor; cylinder head temperature sensor; knock sensor; fuel pump in vapor separator; main power relay; electronic control module; coils.

POWER TRIM & TILT

Trim sending unit; trim pump; pump relief valve; spring; O-ring; trim cylinder(s); tilt cylinder(s); manual release valve; reverse lock valve; power trim and tilt motor; relays; trim manifold.

JET OUTBOARD DRIVE

All internally lubricated parts within pump housing (excluding impeller and impeller liner, and damage to jet drive bearings caused by improper lubrication). Pump housing is only covered if damaged by an internally lubricated part.

IGNITION

Alternator; starter; stator; trigger and starter solenoid; relays; flywheel; voltage regulator; rectifier and regulator assembly; ignition coil(s); ignition module; switch box; power pack (excluding wiring harness).

**In Florida, the administrator is Toyota Motor Insurance Company P.O. Box 650478, Dallas, TX, 75265
Florida License #02871**

Purchase of a Vehicle Service Contract is optional, cancelable (subject to specific agreement terms) and not required to obtain credit. Licensed professional towing agencies' or dealers' receipts will be required for reimbursement. Your Deductible does not apply to this benefit. This brochure is intended as a sample of Vehicle Service Contract coverage.

1 Coverage periods for New Vehicle Plans and Used Vehicle Plans are measured from the Contract Purchase Date. Coverage expires upon reaching the expiration date of the coverage period selected. See your contract for complete terms, conditions, and restrictions.

2 Deductible applies to each eligible repair visit. See your retailer for plan details.

3 Covered components are subject to change. See your contract for complete details.

4 Additional coverage options included when installed at time of boat purchase.

The trade name "Bass Pro Shops Financial Services" and the Bass Pro Shops and Bass Pro Shops Financial Services logos are owned by Bass Pro Intellectual Property, L.L.C. (Bass Pro Shops) or its affiliates and are licensed to Toyota Motor Credit Corporation (TMCC). Voluntary Protection Products are administered by Toyota Motor Insurance Services, Inc. (TMIS), or a third party contracted by TMIS. Bass Pro Shops is solely responsible for its products and services and for promotional statements about them and is not affiliated with TMCC or its affiliates.

TURBOJET DRIVE

All internally lubricated parts within the pump housing (excluding impeller and impeller line, and damage to jet drive bearings caused by improper lubrication). Pump housing is only covered if damaged by an internally lubricated part.

SEALS & GASKETS

Seals and gaskets on all covered parts.

TRAILER

Master cylinder; hydraulic brake actuator; backing plate; axle brackets; bunks; couplers; fenders; hubs; roller cradles; spring hangers; welds; winch stand and suspension springs.

STEERING

Steering control helm assembly; steering bracket and bushing; swivel bracket bearing; control rack and yoke assembly, power steering pump; power steering cylinder; steering wheel and coupling; steering cable.

CONTROLS

Neutral start switch assembly; starter/stop button; throttle control handle; throttle cam and follower; throttle and shift cables; tilt/trim switch; ignition switch (excluding key).

BILGE

Pump; manual control panel; bilge blower and switches.

GAUGES

Speedometer head; tachometer head; speed log; speed sensor; voltmeter; fuel gauge; fuel flow meter and transmitter; trim position gauge; oil pressure gauge; water pressure gauge; engine water temperature gauge; external water temperature gauge; temperature sensor.

COMPASS

compass head.

ELECTRICAL COMPONENTS

Battery main switch; battery isolator; battery selector switch; remote spotlight (control panel, horizontal/vertical control motors, and light housing); bow and marker lights; running lights; cockpit lights; cabin; manual switches; external electric fuel pump for outboard engines; windshield wiper motor. All light bulbs are excluded.

BAITWELL OXYGENATOR

Pump and timer.

LIVEWELL

Washdown pump and livewell pump.

Addition coverage options include: stereo system, navigation/GPS, trolling motor, and more.⁴